

# How to Use Your DVR



With your WOW! DVR, you can watch TV and control it using your remote control.

## WATCHING LIVE TV

### What You Can Do:

- Pause a Show ..... .
- Resume Playback from Pause ..... .
- Rewind a Show ..... .
- Fast Forward ..... .
- Advance One Frame ..... .
- Rewind One Frame ..... .
- Watch Video in Slow Motion ..... .
- Resume Playback from Rewind,  
Fast Forward, or Slow Motion ..... .
- See an Instant Replay ..... .
- Return to "LIVE" TV ..... .

### How to Do It:

- .Press **⏸**
- .Press **⏮** OR **⏹**
- .Press **⏮** once to rewind  
(Note: Press **⏮** multiple times to increase the rewind speed.)
- .Press **⏭** once to fast forward  
(Note: Press **⏭** multiple times to increase the fast forward speed.)
- .Press **⏪**, then press **⏭**
- .Press **⏩**, then press **⏮**
- .Press **⏭** twice quickly  
(within 1/2 second)
- .Press **⏭**
- .Press **⏮**
- .Press **LIVE**

## CREATING A MANUAL RECORDING

While watching TV, go to the Manual Record dialog box by pressing **Ⓞ**, then select "Create a Manual Recording" from the dialog box.

OR

While viewing the "Saved Shows" or "Scheduled Recording" displays, press **Ⓞ**.

## VIEWING SAVED SHOWS

Shows that have been saved can be accessed at any time from the "Saved Shows" display.

To view a saved show, access the "Saved Shows" display by pressing **LIST**.

### What You Can Do:

- Find a Saved Show ..... .
- Play the Highlighted Show ..... .
- Pause a Show ..... .
- Resume Playback from Pause ..... .

### How to Do It:

- .Press **⏪** to highlight a show
- .Press **⏭** OR press **SELECT**, then select "Play," "Play from Beginning," or "Resume Playback" from the dialog box
- .Press **⏸**
- .Press **⏮** OR **⏹**

## MANAGING SAVED SHOWS

### What You Can Do:

- Find a Saved Show ..... .
- Erase a Show ..... .

### How to Do It:

- .Press **⏪** to highlight a show
- .Highlight a show and press **SELECT**, select "Erase" from the dialog box  
(Note: For additional options, highlight a show and press **SELECT**. Use your **⏪** to scroll through the menu options. Press **SELECT** on the option you would like to change.)

**Note:** You can record two live programs and watch a pre-recorded program at the same time. If you are recording two live programs at the same time and attempt to change channels a warning message will appear, warning you that you must stop recording that program in order to proceed.

## WOW! OnDemand

**WOW! OnDemand is free with WOW! Digital Service**, allowing instant access to a continually updated library of over a thousand titles including movies, kids' shows, sports, music videos and events. Also shows from NFL Network, National Geographic Channel and premium networks including HBO, Starz and Cinemax are right at your remote control!\* And most of it is free so you can watch as much as you want. There are also a variety of monthly subscription Video OnDemand channels available for an additional monthly subscription fee, including WWE 24/7 OnDemand, Anime OnDemand and Karaoke OnDemand\*\*.

**Don't miss a thing** with our DVD-like controls. You're in control to pause, fast forward, stop and even rewind your WOW! OnDemand program.

### Watch TV on your schedule.

Watch your WOW! OnDemand programs as many times as you want, for up to 24 hours.

**High-Definition OnDemand** is available to WOW! Digital Cable customers with a WOW! HD receiver. Enjoy your favorite High-Definition movies on WOW! OnDemand, channel 229, without leaving the comfort of your home.

\*Must subscribe to the primary premium channel to receive its OnDemand content.

\*\*Additional monthly subscription required.

## How to use WOW! OnDemand

### GETTING STARTED IS EASY

1. Go to channel 1 in your Digital on-screen guide.
2. Use the up/down arrows to highlight your selection from the categories listed and press SELECT.
3. Use the up/down arrows to highlight the desired category or program and press SELECT.
4. Find the title you want to view and press SELECT. For pay content, if a free preview is available, press the 'B' button to view the preview.
5. Press SELECT to purchase or view the program. If parental controls are activated you may be required to enter your PIN.



It's that kind of experience.